## CHAFING DISH - INSTRUCTION AND TIPS SHEET

## \*CHAFERS WILL ONLY KEEP FOOD WARM\*

- 1. Chafing dish rentals include frame, lid, water pan, food pan and sterno.
- 2. Fill the water pan 1/3 full with hot water. Use less water if you are using the 6qt food pans.
- 3. Transfer prepared food into the food pans or you may use the food pan for cooking.
- 4. Place food pan within the water pan.
- 5. Open the can of sterno and light with a match. It will burn for about 2 hours. Extra sterno cans may be purchased.
- 6. Place cover over chafer to keep the food warm.
  - \*\*CAUTION: HOT STEAM AND MOISTURE COLLECT UNDER THE LID WHILE IN USE. USE CAUTION WHEN OPENING THE LID \*\*
- 7. Sterno cans may be discarded after use, but sterno cups must be returned.
- 8. Please discard left over food before returning the chafing dish.